

## Main Menu

>Format	PAL↵
Video Type	CVI
Video Mode	5M↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Day/Night	Auto↵
Language	English
Advanced	↵
Default	
Exit	

## Backlight Mode

>BLC                    0n  
Return

## Backlight Mode

>WDR 3

Return

Backlight Mode

>HLC 3

Return



## Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

## Exposure

>Exposure Mode Auto↵

Exposure Level 7

Anti-flicker Outdoor

Return

## Auto Exposure

>Gain Max Limit 12

Gain Min Limit 0

Return

Low Noise

>Gain Max Limit 12

Return



## Anti-smear

>Shutter Max 40ms  
Return

## Manual Exposure

>Shutter            1/25  
Gain Max Limit 12  
Gain Min Limit 0  
Return

Area AE

>Area Setting Location↓  
Return




## WB Manual

>Blue Gain      50  
Red Gain      50  
Return



Area WB

>Area Setting    Location↓  
Return



## Day/Night

>Day/Night	6
Night/Day	12
Waiting Time	2
Return	

## Advanced

>Camera Name	Off
Mirror	↓
IR	On
Smart IR	6
Voltage Prompt	On↓
Privacy Mask	Off
System Info	↓
Return	



## Camera Name

- >Name ↵
- Location ↵
- Return



## Mirror

>H-Mirror	Off
Y-Mirror	Off
Return	

Voltage Prompt

>Alarm Upload On  
Return

Privacy Mask

>Area Select 0  
Display On  
Area Setting Location↓  
Default  
Return



## System Info

Version No.

V1.001.0000000.0.R

>Return