

Main Menu

>Format	PAL↵
Video Mode	4K@15↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Day/Night	Auto↵
Language	English
Advanced	↵
Default	
Exit	

Backlight Mode

>BLC

On

Return

Backlight Mode

>WDR 3

Return

Backlight Mode

>HLC

3

Return

Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

Exposure

>Exposure Mode Auto↵
Exposure Level 7
Anti-flicker Outdoor
Return

Auto Exposure

>Gain Max Limit 12
Gain Min Limit 0
Return

Low Noise

>Gain Max Limit 12
Return

Anti-smear

>Shutter Max 40ms
Return

Manual Exposure

>Shutter 1/25
Gain Max Limit 12
Gain Min Limit 0
Return

WB Manual

>Blue Gain	50
Red Gain	50
Return	

Area WB

>Area Setting Location↵
Return

Day/Night

>Day/Night	6
Night/Day	12
Waiting Time	2
Return	

Advanced

>Camera Name	Off
Mirror	↵
Audio Mode	Built-in Mic↵
IR	On
Smart IR	7
Voltage Prompt	On↵
Privacy Mask	Off
System Info	↵
Video Type	CVI
Return	

Camera Name

>Name ↵
 Location ↵
 Return

Camera Name

00000000

—

↑

←

OK

→

↓

Mirror

>H-Mirror	Off
V-Mirror	Off
Return	

Audio Mode

>Volume
Return

High

Voltage Prompt

>Alarm Upload On
Return

Privacy Mask

>Area Select 0
Display 0n
Area Setting Location↵
Default
Return

System Info

Version No.

V1.001.0000001.0.R

>Return

Save

>Yes

No

Cancel