

Main Menu

>Format PAL↵
Video Mode 1080P@25↵ CVI
Backlight Mode Off
Image Adjust ↵
Exposure ↵
White Balance Auto
Day/Night Auto↵
Language English
Advanced ↵
Default
Exit

Backlight Mode

>BLC On
Return

Backlight Mode

>WDR 3
Return

Backlight Mode

>HLC 3
Return

Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

Exposure

>Exposure Mode Auto␣
Exposure Level 7
Anti-flicker Outdoor
Return

Auto Exposure

```
>Gain Max Limit 12  
Gain Min Limit 0  
Return
```

Low Noise


>Gain Max Limit 12
Return

Anti-smear

>Shutter Max 40ms
Return

Manual Exposure

>Shutter 1/25
Gain Max Limit 12
Gain Min Limit 0
Return



Area AE

>Area Setting Location┘
Return

WB Manual

>Blue Gain	50
Red Gain	50
Return	

Area WB

>Area Setting Location↓
Return

Day/Night

>Day/Night	6
Night/Day	12
Waiting Time	2
Return	

Advanced

>Camera Name	Off
Mirror	↵
Audio Mode	Built-in Mic↵
IR	On
Smart IR	7
Voltage Prompt	On↵
Privacy Mask	Off
System Info	↵
Video Type	CVI
Return	

Camera Name

- >Name ↵
- Location ↵
- Return

Mirror

>H-Mirror	Off
V-Mirror	Off
Return	

Audio Mode

>Volume
Return

Medium

Voltage Prompt

>Alarm Upload On
Return

Privacy Mask

>Area Select 0
Display On
Area Setting Location↓
Default
Return

System Info

Version No.

V1.001.0000000.2.R

>Return