

## Main Menu

>Format            PAL↵  
Video Mode        1080P@25↵ CVI  
Backlight Mode   Off  
Image Adjust     ↵  
Exposure          ↵  
White Balance    Auto  
Light             Smart Light↵  
Language          English  
Advanced          ↵  
Default  
Exit

## Backlight Mode

>BLC                    On  
Return

## Backlight Mode

>WDR 3  
Return

Backlight Mode

>HLC 3  
Return

## Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

## Exposure

>Exposure Mode Auto ↵  
Exposure Level 7  
Anti-flicker Outdoor  
Return

## Auto Exposure

>Gain Max Limit 12  
Gain Min Limit 0  
Return

## WB Manual

>Blue Gain      50  
Red Gain        50  
Return



Area WB

>Area Setting Location↓  
Return

## Smart Light

>Level            5  
Sensitivity      3  
Return

## Advanced

>Camera Name    Off  
Mirror           ↓  
Audio Mode     Built-in Mic↓  
Voltage Prompt On↓  
Privacy Mask   Off  
System Info    ↓  
Video Type     CVI  
Return

## Mirror

>H-Mirror	Off
V-Mirror	Off
Return	

Audio Mode

>Volume  
Return

Medium

Voltage Prompt

>Alarm Upload On  
Return

## Privacy Mask

>Area Select 0  
Display On  
Area Setting Location  
Default  
Return

System Info

Version No.

V1.000.0000001.2.R

>Return