

Main Menu

>Format	PAL↵
Video Type	CVI
Video Mode	5M↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Alert	↵
Light	Smart Light↵
Language	English
Advanced	↵
Default	
Exit	

Backlight Mode

>BLC 0n

Return

Backlight Mode

>WDR 3

Return

Backlight Mode

>HLC 3

Return

Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

Exposure

>Exposure Mode Auto↵
Exposure Level 7
Anti-flicker Outdoor
Return

Auto Exposure

>Gain Max Limit 12

Gain Min Limit 0

Return

Low Noise

>Gain Max Limit 12

Return

Anti-smear

>Shutter Max 40ms

Return

Manual Exposure

>Shutter 1/25
Gain Max Limit 12
Gain Min Limit 0
Return

Area AE

>Area Setting Location↓
Return

WB Manual

>Blue Gain 50
Red Gain 50
Return

Area WB

>Area Setting Location↵
Return

Alert

>Light Warning On↵
Audio Alert On↵
Alarm Output On
Return

Light Warning

>Flash Freq. Medium

Alert Duration 30

Return

Audio Alert

>Audio Audio 1
Volume High
Alert Duration 30
Return

Main Menu

Format	PAL↵
Video Type	CVI
Video Mode	5M↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Alert	↵
>Light	Smart Light↵
Language	English
Advanced	↵
Default	
Exit	

Smart Light

>Level 5
Sensitivity 3
Return

Smart Light

>Level 3

Return

Advanced

>Camera Name Off
Mirror ↵
Voltage Prompt On↵
Privacy Mask Off
System Info ↵
Return

Camera Name

>Name ↵
Location ↵
Return

Mirror

>H-Mirror Off

V-Mirror Off

Return

Voltage Prompt

>Alarm Upload On

Return

Privacy Mask

>Area Select 0
Display On
Area Setting Location↵
Default
Return

System Info

Version No.

V1.001.000000.5.R

>Return

Save

>Yes

No

Cancel